

FUSE BLOCK (2-Pole Kit)

(former Catalog # FKTP-1001)


Contents:

Item # 04 = (2) 1-Pole Plastic Fuse Covers

Item # 03 = (2) 8/32 x 1/2 Screws (M w/Covers)
8/32 x 1/4 Screws (M w/o Covers)
6/32 x 1/2 Screws (D w/Covers)
6/32 x 1/4 Screws (D w/o Covers)

Item # 02 = (2) Black Plastic L-Bracket

Item # 01 = (1) 2-Pole Fuse Block



ASSEMBLY MOUNTING INSTRUCTIONS

1. Remove the screws securing the fuse block to the mounting plate.
2. Orient the locking clips (1), as shown above, and insert into fuse block.
3. Attach and secure the locking clips and fuse block to the mounting plate with the longer screws (2) supplied.
- Recommended torque: 12 IN-LB
4. Insert fuse block covers (3) with lock slots (3A) turned toward the tip of the locking clips.
Press down until the covers snap into place.